

# 32KB RAM EXPANSION


*PAL-1*

2021-02-18

## MANUAL

---

Use BOM symbol information to assemble the RAM expansion kit, the finished expansion card looks like this:



Power off your PAL-1, connect the card to PAL-1 SBC using the motherboard card or a 40pin female/female IDC cable.

Please check if the pin 1 of the expansion card is aligned with the pin 1 of the motherboard socket or PAL-1 expansion port.

After connected, the computer system looks like this:



Connect via mainboard



Connect by cable

Then, open the memory selector jumper on PAL-1 to complete RAM expansion.



Power up and reset PAL-1, the RAM space from \$2000 to \$9FFF now can be accessed by PAL-1's processor, just try running a big program like the Microsoft BASIC on your PAL-1.